

# INSTRUCTION GUIDE

## TRICROSS FRONT BRAKE HANGER



THIS BRIEF INSTALLATION GUIDE CONTAINS IMPORTANT INFORMATION.  
PLEASE READ CAREFULLY AND STORE IN A SAFE PLACE.

Congratulations! The Specialized product you have chosen is among the finest available in cycling. This short form installation guide contains instructions and warnings, plus torque specifications, to be used in conjunction with the owner's manuals and instruction guides supplied with your bicycle.

**WARNING!** Failure to follow these instructions may result in a catastrophic failure while riding, which may result in serious personal injury or death.

**WARNING!** Bicycle assembly is a complicated task which requires training and experience. Do not attempt installation of any component if you do not have experience and training as a bicycle mechanic. Specialized recommends that the Tricross Fork Brake Hanger be installed by a qualified technician at an Authorized Specialized Retailer. Incorrect assembly of the brake hanger can cause the front brake to lock up, which can result in serious personal injury and/or death.

**WARNING!** Failure to follow the torque specifications in this installation guide will void your warranty, but most importantly may result in damage to the components which may not be visible. If the components are damaged, this can result in loss of structural integrity, which may result in serious personal injury or death. To ensure the best assembly possible and to prevent any damage to the components, follow all torque specifications.

### CABLE HANGER INSTALLATION

The Specialized Tricross Fork Brake Hanger is designed to reduce front brake chatter. To ensure proper function, please follow the instructions below.

- Place the correct L-shaped adapter tab (short fits alloy fork crowns, long fits carbon fork crowns) against the underside of the crown to align the brake hanger vertically.
- Insert the correct steel bolt receptor (long fits alloy fork crowns, short fits carbon fork crowns) into the back of the fork crown then apply loctite to the bolt. Place the cable hanger against the L-shaped adapter, then thread the bolt into the steel bolt receptor.
- Tighten the bolt to 70 in-lbf (7.9 N\*m).
- Install the correct length brake cable housing and ferrule, then install the brake cable. Adjust the brakes as directed by the brake manufacturer.

For the complete warranty provisions, please refer to [www.specialized.com/tech](http://www.specialized.com/tech).

**NOTE** - When installing fenders, do not use the L-shaped adapter tab, only use the cable hanger.

